


# BUTTON MOULDS & ACCESSORIES

## BUTTON MOULDS (COMPLETE)

- Box contains 5 gross each of Regular Shells and Lip-Lok Wire Eye Backs.
- 106101 #22 Button Moulds (Complete)
- 106102 #30 Button Moulds (Complete)

## NYLON COLLETS

- For automotive and marine applications as well as furniture uses.
- Used with #30 Shells & #457 Fasteners. (see page 13)
- 106179 #30-2706 Nylon Collets




Button Shell  
Nylon Collet



#457 Fastener

## PRONG BACKS

- Prongs are quickly & easily secured by simply bending them 90° after insertion.
- Use #2CL Prong Washers or #SPWSHR-015 Spring Washers to secure prongs more firmly.



Prong Back

105421 #2CL 15/16"  
Prong Metal Washer

## D-line Prong Backs


- 106111 #22 1 1/2"      106115 #30 2"
- 106112 #22 2"      105418 #36 2"
- 106113 #22 2 1/2"      106119 #36 2 1/2"

## Lip-Lok Prong Backs

- 105411 #22 1 1/2"      105415 #30 2"
- 105412 #22 2"      105416 #30 2 1/2"
- 105413 #22 2 1/2"      105419 #36 2 1/2"

## THREADED NO-DENT-NAILS

- Backs are welded to 3/4" deeply threaded nails which can be used with #SPWSHR-015 Spring Washers as an alternative to prong tufting.
- 105434 #22-2900 Threaded No-Dent-Nails
- 105461 #30-2900 Threaded No-Dent-Nails
- 105467 #45-2900 Threaded No-Dent-Nails



#2900 No-Dent-Nail

106124 #SPWSHR-015  
Spring Steel Lock Washer

## NYLON HOOK BACKS



- Use with #30 Aluminum Shells for a completely rust-proof button.
- 106191 #30-330 Nylon Hook Backs

## MOLDED NYLON BUTTONS



- For use on casual/outdoor furniture or wherever a weatherproof button is desired.
- 106190 #40-3200 Nylon Buttons - Vanilla
- 105457 #40-3200 Nylon Buttons - White